



MARS MeetMe Password

MARS MeetMe Password application is an add-on to Cisco CUCM Meet Me Conference application.

MARS Meet-Me Password application adds the following capabilities

1. Remotely start the MeetMe conference 
2. Authentication/Password for MeetMe Conference 
3. Meeting Host Required/Not Required 
4. Start/Join the MeetMe Conference from Jabber Client
5. Start/Join the MeetMe Conference from iOS Based Mobile Phone , Android Based Mobile Phone, Land Line

Remotely start the MeetMe conference

The application enables a conference host or participant to start the Meet-Me conference remotely by dialing the application IVR number, i.e. the conference host or participant need not be physically present on his desk to start the conference using a Cisco IP Phone.

The Meet Me conference can be started from any PSTN number or from any Cisco IP Phone registered to the enterprise CUCM.

Authentication/Password for MeetMe Conference

For an MARS Meet-Me Password enabled Cisco Meet Me Conference, a user needs to authenticate himself before he can join the Meet Me conference.

To join a meeting, participants need to dial an application IVR number and enter the provided Meeting ID & Password on the IVR. The application authenticates the credentials entered by the participant and valid participants are passed on to join the conference for Cisco Meet Me Number registered against the entered Meeting ID.

Once the user is authenticated by the application, the call leg/control is passed on to the Cisco CUCM Meet-Me application.

The number of actual CUCM Meet-Me concurrent conferences and maximum number of participants in each conference depends on available Meet-Me resources. Please refer to Cisco CUCM guidelines for the same.

Meeting Host Required/Not Required

The application enables a conference with the feature whether the meeting host is required or not for the meeting.

If it is set as “Host Password Required” then the Meeting Host needs to first join the conference before the other participants can join the conference.


The meetings are configured in the application by the application administrator using a windows client based application.

The Cisco CUCM Meet-Me number is exposed only to the application administrator.

Participants are provided by the application administrator an application generated Meeting ID & password which is required to join the Meet-Me.

Enterprise users need to remember just one phone number for the MeetMe conferences. The application uses the Meeting ID & PIN entered to connect the attendee to the correct meeting/MeetMe Number.

The application administrator can set the validity for a conference by setting the start & end dates of a conference.



Supporting Hardware & Software:		
1.	CUCM Supported	8.x,9.x,10.1,10.5,BE 6000,BE 7000
2.	Phones supported	7861, 7940, 7941, 7942G, 7945, 7960, 7961, 7962,797x, 89xx, 99xx, IP Communicator. For other phone models please contact Parsec. A Cisco IP Phone dedicated to the application should be provided. This IP phone should not be assigned to any user. MeetMe service should be configured & running on Line2 of that Cisco IP Phone.
3.	Application Server Details	Intel Xeon Quad Core 2.3 + RAM : 8 GB+,HDD : 70 GB+ Windows Server 2008 R2 64 Bit /Windows Server 2012 R2 64 Bit VMware supported